

CB3-5 / CB5-7 CB5-9 / CB9-15

Counter Balancer Hanger



OPERATIONS and MAINTAINANCE MANUAL



BEFORE OPERATING THIS DEVICE, ALL OPERATORS SHOULD READ AND STUDY THIS MANUAL TO UNDERSTAND AND FOLLOW THE SAFETY WARNINGS AND INSTRUCTIONS. KEEP THESE INSTRUCTIONS WITH THE DEVICE FOR FUTURE REFERENCE.

Everwin Pneumatic Corp.

19"/3/19

INDEX

CE Declaration of Conformity	2
Safety Instructions	3~5
Specifications and Technical Data	6~7
Installation	8
Check Before Use	8

CE DECLARATION OF CONFORMITY

CE Declaration of conformity	ENGLISH
EVERWIN PNEUMATIC CORP. declares that the product as described in attached	documentation is in conformity
with the Machinery Directive 2006/42/EC and the European standard EN 792-13.	
CE Dichiarazione di conformità	ITALIANO
EVERWIN PNEUMATIC CORP. dichiara, assumendo la piena responsabilità, che	questa fissatrice e conforme alla
Direttive Europee 2006/42/EC e alla norma armonizzata EN 792-13.	
CE Konformitätserklärung	DEUTSCH
EVERWIN PNEUMATIC CORP. erklärt hiermit in alleiniger Verantwortung das dies	ses Gerät ubereinstimmt mit den
Europäischen Richtlinien 2006/42/EC und den Europäischen Norm EN 792-13.	
CE Déclaration de conformité	FRANCAIS
EVERWIN PNEUMATIC CORP. déclare et prend sur soi toute la responsabilité de	
en conformité avec les Directives Européennes 2006/42/EC et avec la norme hann	
CE konformiteitsverklaring	NEDERLANDS
EVERWIN PNEUMATIC CORP. verklaart hierbij onder eigen verant woordelijkheid	
overeenstemming is met de Europese Richtlijnen 2006/42/EC en de Europese nor	
CE Declaracion de conformidad	ESPAGNOL
EVERWIN PNEUMATIC CORP. declaramos bajo nuestra sola responsabilidad que	
conformidad con las Directivas Europeas 2006/42/EC y con la normativa EN 792-1	13.
Overensstemmelseserklæring / CE Deklaration	DANSK
EVERWIN PNEUMATIC CORP. erklærer herved, at produktet er i overenstemmels	
normative dokumenter 2006/42/EC i henhold til bestemmelserne i EU's direktiv EN	
Överstämmelseförklaring / CE Deklaration	SVENSK
EVERWIN PNEUMATIC CORP. förklarar härmed att produkten överensstämmer n	ned följande normer och direktiv
2006/42/EC och SS-EN 792-13.	
SAMSVARSERKLÆRING / CE Deklaration	NORSK
EVERWIN PNEUMATIC CORP. erklærer herved att produktet er i samsvar med fø	Igende normer og direktiv 2006/42
EC og NS-EN 792-13.	
Todistus CE standardinmukaisuudesta	FINSK
EVERWIN PNEUMATIC CORP. vakuuttaa täten tuotteen vastaavan seuraavla star	ndardeja ja direktiivejä: 2006/42/EC
ja EN 792-13.	
Deklaracja zgodności CE	POLSKIE
EVERWIN PNEUMATIC CORP. oświadcza, że produkty opisane w załączonej doł	kumentacji spełniają wymogi
Dyrektywy Maszynowej 2006/42/EC oraz Europejskiej normy EN 792-13.	

Machine Type: CB3-5, CB5-7, CB5-9, CB9-15

Machine Name: Counter Balancer Hanger

Place of Issue: No. 7, Wugong 7th Rd., Wufeng Dist., Taichung City 41353, Taiwan.


Date of Issue: Mar. 19, 2019

Lolio

Signature of Issuer:

Hung-Ming Chuang General Manager


SAFETY INSTRUCTIONS




SAFETY INSTRUCTIONS



To avoid severe personal injury or property damage, READ and STUDY this manual before use of tool.




Never stand under the counter balancer hanger.




Do not disassemble or modify the product.





Avoid contact with fluids at all times.



Do not twist and rub the cordage with cable during travel. Do not load over the stated capacity.

SAFETY INSTRUCTIONS




The use through overly big angles will reduce lifespan of rope. **Recommended range of** angle: $\pm 20^{\circ}$



Detach tool while removing the counter balancer hanger to prevent the device from dropping.



Make sure to detach counter balancer hanger and tool when not in use.



Secondary support cable or chain

Leave some slack in the secondary support cable or chain to allow the hanger to rotate freely. The slack must be a suitable length so that the hanger will stop within 10 cm when falling by accident.




Make sure to remove the counter balancer hanger and tool before setting up tension.



Application area: Indoors and outdoors with normal atmospheric conditions.


Temperature range: -10° C ~+40 $^{\circ}$ C

SPECIFICATIONS AND TECHNICAL DATA



Model	Weight Capacity	Hanger Weight	Cable Length	Cable Dia.
CB3-5	3~5 kg	1.82 kg	130 cm	3.2 mm
	6.6~11 lbs.	4 lbs.	52 in	0.13 in
CB5-7	5~7 kg	1.85 kg	130 cm	3.2 mm
	11~15.5lbs.	4.1 lbs.	52 in	0.13 in

SPECIFICATIONS AND TECHNICAL DATA



Model	Weight Capacity	Hanger Weight	Cable Length	Cable Dia.
CB5-9	5~9 kg	3.59 kg	130 cm	4.0 mm
	11~19.8 lbs.	7.9 lbs.	52 in	0.16 in
CB9-15	9~15 kg	3.61 kg	130 cm	4.0 mm
	19.8~33 lbs.	8 lbs.	52 in	0.16 in

INSTALLATION:

- 1. Attach the counter balancer hanger to a steady location.
- 2. Attach a secondary support cable and install it to a steady location.
- 3. Install tool within the weight capacity to the bottom hook.
- 4. Adjust tension to appropriate level after tool installation.

CHECK BEFORE USE:

- 1. The hanger and bottom hook are steady and rotate smoothly.
- 2. The cable is undamaged.
- 3. The ratchet, ratchet spring, and spindle are steady.
- 4. The counter balancer hanger is undamaged and apparently sound.